# STONE SHIELDS



Protect your RV, and prolong the life of its paintwork by installing a Stone Shield. Supplied as a flat pack, it is quick and easy to install on the A-frame of your caravan or camper trailer.

Made from tough rip stop mesh (resistant to rips or tears), the Stone Shield stops stones (and other hard debris) from chipping, or potentially even denting your RV's paintwork. Comes with two extra-large rubber mud flaps to protect the undercarriage of your caravan or camper trailer.

## **CARAVAN STONE SHIELD**

#### 450-06500

- > 2310 x 500 (mm)
- > Net Weight: 16.0kg

## CAMPER VAN STONE SHIELD

#### 450-06510

- > 2150 x 500 (mm)
- > Net Weight: 15.7kg

### **CAMPER TRAILER STONE SHIELD**

#### 450-06520

- > 1800 x 500 (mm)
- > Net Weight: 14.8kg

