

Sizzler

CARAVAN BARBECUES

Where performance, space, reliability, and flexibility count, get **HOT** with a **SIZZLER!** The hottest caravan barbecue on the market! Designed to be lightweight yet strong enough for Australia's tough outback conditions, our barbecues take up less than half the space of the competition but have a larger cooking area.

Suitable for your caravan, RV or camper trailer.



THEY'RE **HOT!** 20,000 BTU'S OR 21 MEGAJOULES

TWO INDEPENDENT BURNERS, BOTH FITTED WITH FLAME FAILURE VALVES!

3MM SOLID STAINLESS STEEL HOTPLATE, EASY TO CLEAN

BARBECUE, OVEN AND COOKTOP ALL IN ONE (WITH OPTIONAL COOKING RACK)

HEAT RESISTANT GLASS WINDOW, WATCH WHAT YOU ARE COOKING

SLIDE SYSTEMS AVAILABLE TO FIT YOUR TUNNEL BOOT!




NEW Sizzler Deluxe & Sizzler Max

NEW FLAME FAILURE (GAS CUT OFF PROTECTION)

Our BBQs are AGA Certified!

All our Sizzler BBQs are fitted with thermo couplers. A thermo coupler device is designed to cut off the gas supply should the flame go out. This enables the Sizzler to be connected to your bayonet fitting on your Caravan or RV.



NEW SLIDES

Swivel and Straight Slides are now lockable.



Sizzler Deluxe High Lid Barbecue on **New Locking Swivel Slide**

NEW FEET

All our new Sizzlers now come with removable feet, which can be height adjusted. Remove the feet for slide operation or adjust height to suit your table surface.



Underside





SIZZLER DELUXE HIGH LID BARBECUE

**The most multifunctional
barbecues on the market**

SIZZLER DELUXE HIGH LID AND SIZZLER MAX HIGH LID FEATURES:

- All stainless steel construction.
- Two independent stainless steel burners.
- Two independent Thermo Couplers.
- 'Auto Shut Off' control valves.
- Large stainless steel hot plate.
- Viewing window. You can watch what you're cooking.
- Removable legs. Put your Sizzler on a plastic table.
- Fits our Swivel, Straight, Low Profile and Generator slides.
- Optional cooking rack which converts BBQ to cooktop or oven!

DIMENSIONS:

260mm H x 530mm W x 305mm D (lid closed)

COOKING SURFACE:

440mm W x 250mm D



Roasting a 2 kilo chicken or leg of ham is easy in the Sizzler Deluxe.



Using the Sizzler Deluxe as a **stove top**.



SIZZLER MAX **HIGH LID BARBECUE**

**50% bigger than Sizzler Deluxe
with a larger cooking surface**



DIMENSIONS:

260mm H x 530mm W x 400mm D (lid closed)

COOKING SURFACE:

440mm W x 350mm D

**ENJOY A
LARGER
COOKING
SURFACE!**



SIZZLER DELUXE **LOW LID BARBECUE**

**IDEAL FOR
RESTRICTED
AREAS**




DIMENSIONS:

175 H x 530 W x 340mm D
(lid closed)

COOKING SURFACE:

440mm W x 250mm D



**Sizzler Deluxe
Low Lid Barbecue
with lid closed.**



**Sizzler Deluxe Low Lid
Barbecue on the low profile
straight slide.**

Sizzler Slide Options

QUICK RELEASE SWIVEL SLIDE



SIZZLER DELUXE
Width 335mm
Depth 530mm
Height 95mm

SIZZLER MAX
Width 335mm
Depth 630mm
Height 95mm



SIZZLER DELUXE
LOW LID ON SLIDE
Width 350mm
Depth 570mm
(includes control panel)
Height 235mm



SIZZLER DELUXE
HIGH LID ON SLIDE
Width 345mm
Depth 570mm
(includes control panel)
Height 310mm



SIZZLER MAX
ON SLIDE
Width 405mm
(includes tightening knob)
Depth 630mm
Height 310mm

QUICK RELEASE STRAIGHT SLIDE



SIZZLER DELUXE
Width 455mm
Depth 530mm
Height 95mm

SIZZLER MAX
Width 455mm
Depth 630mm
Height 95mm



SIZZLER DELUXE
LOW LID ON SLIDE
Width 540mm
(includes tightening knob)
Depth 575mm (includes handle)
Height 235mm



SIZZLER DELUXE
HIGH LID ON SLIDE
Width 540mm
(includes tightening knob)
Depth 530mm
Height 310mm



SIZZLER MAX
ON SLIDE
Width 560mm
Depth 630mm
Height 310mm

LOW PROFILE STRAIGHT SLIDE



SIZZLER DELUXE
Width 555mm
Depth 530mm
Height 50mm

SIZZLER MAX
Width 555mm
Depth 630mm
Height 50mm



SIZZLER DELUXE
LOW LID ON SLIDE
Width 585mm
Depth 575mm (includes handle)
Height 185mm



SIZZLER DELUXE
HIGH LID ON SLIDE
Width 585mm
Depth 530mm
Height 260mm



SIZZLER MAX
ON SLIDE
Width 585mm
Depth 660mm
Height 260mm

SIZZLER DELUXE GENERATOR SLIDE



SLIDE
Width 290mm
Depth 450mm
Height 110mm


NEW

To suit **SIZZLER DELUXE HIGH LID**
and **SIZZLER DELUXE LOW LID** only.

Specially designed to fit within the
generator compartment of your van.



Optional Accessories



Cooking Rack

Fits directly over the top of the burners, giving close contact with the heat. By removing the hotplate and inserting the Cooking Rack, the barbecue becomes a stove-top or an oven.



BBQ Utensil Tray

The tray clips onto the front of your BBQ. It is ideal for storing your utensils or condiments while cooking.



Baking Dish

Made of 443 grade stainless steel designed to fit right across the back of the Sizzler Deluxe and Sizzler Max.



Optional Gas Hose and Regulators

(bottle not included)



Stainless Steel Hot Plate – Half Grill/Half Flat

Requires gas burners with ½ flame dispersers.



Stainless Steel Hot Plate – Full Grill

Requires gas burners with full flame dispersers.



Swivel Top Plate

Available in mild steel and 430 stainless steel. To suit pull out kitchens.

How to use our Quick Release Swivel Slide

TO SET UP:



Step 1 Release locking devices and pull out until it locks.



Step 2 Swivel the barbecue in a clockwise direction to face you.



Step 3 Pull barbecue all the way forward and you're ready to use.

TO PACK AWAY:



Step 1 Slide barbecue back to centre position.



Step 2 Swivel the barbecue anticlockwise to sideways position.



Step 3 Release locking devices and slide the barbecue all the way back until it locks.

Dealer information:

Disclaimer: As we are constantly adding, improving and refining our range of barbecues and accessories, their price and specifications are subject to change without notice.

Caravan and Marine Barbecues www.marinebarbecues.com.au

Unit 5, 9 Sky Close, Taylors Beach NSW 2316 AUSTRALIA

Phone +61 2 4981 9859 Fax +61 2 4982 2086 Email sales@marinebarbecues.com.au

